



Motion Detection Sensitivity Setting

You can adjust the sensitivity of motion detection by ifcam mobile App. Login Sricam App , tap Setting button >> "Settings" >> "Alarm setting"



Note: "0" represents a very sensitive, "6" represents the lowest sensitivity.